


How to Uninstall ThunderMax Software


On the bottom right of your Desktop, click on the **Start** button and choose **Computer**.




At the top of the screen, choose **Uninstall or Change a Program**.




Next, 'double-click' either **SmartLink** or **Tmax Tuner**.



In a few seconds, an *Install Wizard* screen should appear. Click **Remove**, and click **Next**.



A **Confirm Install** screen will appear. Click **OK**.






HOW TO:



An *Install Wizard* screen should appear. Click **Finish**.



At this point the ThunderMax Program should be Uninstalled.



THUNDERMAX
120 INDUSTRIAL DRIVE
WHITE HOUSE, TN 37188

SUPPORT@THUNDER-MAX.COM
WWW.THUNDER-MAX.COM
@THUNDERMAXEFI

